
Location Tracking


Location Tracking






Track the location, in real time, of the device.

"Live" Current Lat/Lng






Changes in simulator to be reflected immediately in app

Display Current Marker Lat/Lng

Modify EditLocation to display lat/Ing for marker as dragged around map





Revised Approach: Request Location Update Stream

To store parameters for requests to the fused location provider, create a LocationRequest.

The parameters determine the level of accuracy for location requests - including the update interval, fastest update interval, and priority

New Helper function to create a location request object

```
@SuppressLint("RestrictedApi")
fun createDefaultLocationRequest() : LocationRequest {
  val locationRequest = LocationRequest().apply {
    interval = 10000
    fastestInterval = 5000
    priority = LocationRequest.PRIORITY_HIGH_ACCURACY
  }
  return locationRequest
}
```

Revised PlacemarkPresenter

location request parameters in new attribute

```
...
val locationRequest = createDefaultLocationRequest()
...
```

A call-back function which will be triggered by the fused location service

```
var locationCallback = object : LocationCallback() {
   override fun onLocationResult(locationResult: LocationResult?) {
    if (locationResult != null && locationResult.locations != null) {
      val l = locationResult.locations.last()
      locationUpdate(l.latitude, l.longitude)
    }
}
```

Revised PlacemarkPresenter

```
@SuppressLint("MissingPermission")
fun doResartLocationUpdates() {
 var locationCallback = object : LocationCallback() {
    override fun onLocationResult(locationResult: LocationResult?) {
                                                                                         Encapsulated
      if (locationResult != null && locationResult.locations != null) {
        val l = locationResult.locations.last()
                                                                                         callback
        locationUpdate(Location(l.latitude, l.longitude))
  if (!edit)
    locationService.requestLocationUpdates(locationRequest, locationCallback, null)
```

If in edit mode (i.e. this is a new placemark), request a location update stream

Revised PlacemarkPresenter

PlacemarkPresenter

```
if (locationResult != null && locationResult.locations != null) {
  val l = locationResult.locations.last()
  locationUpdate(Location(l.latitude, l.longitude))
}

fun locationUpdate(location: Location) {
  //...
  view?.showPlacemark(placemark)
}
```

Lat: 52.245695 Lng: -7.139102





```
override fun showPlacemark(placemark: PlacemarkModel) {
    lat.setText("%.6f".format(placemark.location.lat))
    lng.setText("%.6f".format(placemark.location.lng))
}
```

PlacemarkView

EditLocationView

```
class EditLocationView : BaseView(), GoogleMap.OnMarkerDragListener {
  • • •
  override fun onCreate(savedInstanceState: Bundle?) {
   mapView.onCreate(savedInstanceState);
   mapView.getMapAsync {
      it.setOnMarkerDragListener(this)
      presenter.doConfigureMap(it)
  override fun onMarkerDrag(marker: Marker) {
    lat.setText("%.6f".format(marker.position.latitude))
    lng.setText("%.6f".format(marker.position.longitude))
```

